



Amplifier and Hub Wiring

Channel 1 Hallway Zone

When adding multiple speakers to a daisy chain they will need be wired in parallel. The wattage of each speaker in the chain added together should not exceed 80% of the channels maximum wattage.

Channel 2 Exterior Zone

Terminal Strip

G2 70 Volt Amplifier





Image for Visual Example

When wiring, be sure to wire the audio level appropriate for the installation location.

Exterior Hub



Hallway Hub

